


DC GENERATOR




SHOWN FOR CLOCKWISE ROTATION
(FACING SHAFT)
FOR COUNTERCLOCKWISE ROTATION
INTERCHANGE LEADS A1 AND A2

WIRING DIAGRAM


SIEB 5KW & 10KW MAGNET SYSTEMS
4295 AUTOMATIC DROP CONTROLLER
SIZE 1 OR 2, 230 VDC for MAINTAINED MASTER SWITCH

SAFETY DISCONNECT





8/2 CABLE

8/2 CABLE



MAGNET

CONTROLLER



MAGNET MASTER SWITCH

NOTES:

1. SAFETY FIRST! DISCONNECT ALL POWER SOURCES WHEN WIRING THE EQUIPMENT.
2. WARNING! FULL 230 VDC AT MASTER SWITCH.



SIEB SALES & ENGR., INC.
10001 EXPRESS DR.
HIGHLAND, IN 46322
www.siebsales.com

CALL 219-924-3616
FOR ASSISTANCE

REV. 072308